




Position	Part number	Název	Name
3	HECHT001670	Kotouč 150x10x1,6 24Z	Saw blade 150x10x1,6 24T
22	H167022	Pravítko	Ruler
35	H167035	Mikrospínač	Microswitch
41	H167041	Spínač	Switch
47	HECHT001277BX	Akumulátor 20V2Ah	Battery 20V2Ah
	HECHT001278BX	Akumulátor 20V4Ah	Battery 20V4Ah
48	HECHT001277CH	Nabíječka	Charger